


XP312, XP416, XP12 & XP16

Parts breakdown



N.	P/N	DESCRIPTION	Qty	N.	P/N	DESCRIPTION	Qty
1	1198800	Washers and lock rings set (repair)	1	24	502757	Strap buckle	2
2	1210725	Gasket holder XP	1	25	1168421	Lever assembly LP-3	1
3	1168409	Gasket (felt)	1	26	1168422	Trigger valve needle assembly LP-3	1
4	1168407	Piston cup (Santoprene™)	1	27	1168419	Trigger valve assembly LP-3	1
5	1168406	Chamber with piston cup	1	28	635276	Elbow with cone packing	1
6	1168404	O-ring ORI-033	1	29	100131	Lance 601	1
7	1168405	Chamber cylinder	1	30	1180613	Spring	1
8	1168410	Stainless steel ball	1	31	592139	Nozzle filter M40	1
9	560573	Lid diaphragm	1	32	325787	Blue adjustable cone nozzle	1
10	1210726	Lid with diaphragm XP	1	33	942201	Outlet tube	2
11	1168414	Strainer XP	1	34	231845	O-ring 110	2
12	1210727	Tank base	1	35	1168544	Trigger valve cap	1
13	1168397	Base lock	2	36	915744	Screw cap	2
14	1211809	Tank XP312 with lock (white)	1	37	1176816	Lance LP-3 assembly	1
14A	1211810	Tank XP416 with lock (white)	1				
14B	1200395	Tank XP12 with lock (blue)	1				
14C	1200398	Tank XP16 with lock (blue)	1				
15	883108	Axle with lock	1				
16	1197400	Pumping rod XP (orange)	1				
17	495648	Handgrip assembly	1				
18	615005	Lever assembly (orange)	1				
19	635664	Strap lock	1				
20	1176504	Strap assembly with adjustment XP	1				
21	942193	Screw cap S20	2				
22	1168403	Hose assembly XP	1				
23	1168418	Filter LP-3	1				